

FPM-WSA52 Demo

User Guide

Model No.	FPM-WSA52
Type	USB



2017-03-14

Version1.0

Digimore Electronics Co., Ltd
10 FL., No. 61, Yan-Ping S. Rd.
Taipei 10043, Taiwan
TEL: +886 2 2311 3299

1. Power and Connection

- USB 5V
- Connection to PC or laptop by Micro USB to / CON202

Front View (Sensor side)





Rear View (Components side)



2. Demo AP

- WWWJP2000MG512_V3.13.exe




3. Operation 1 – Connection and Open Device

- Connection FPM-WSA52 (CON202) to PC or laptop by Micro USB
- Execute the AP
 - ** Make sure the Serial Port Number is USB and Baudrate is 115200
- Then Open Device by click Icon [Open]




- Check Result Window: If success, it will show the version and SN of device in result window.




4. Operation 2 - Start to Enroll

- Select the ID 0 (Max is 120, 0~119)
- Click the Icon [Enroll] to start




5. Operation 3 – Enroll Process


- In the Result window, the AP will ask you **Input finger 1!**
 - Put the finger on sensor; After capture the finger image, the AP will ask you to **Take off finger** for next snapping.
 - The AP will ask you **Input finger 2 !**



- c. It will take 3 snapping each finger enrolment.
- If the snapping is not good or timeout, the AP will show the message in the Result window




- When the enrollment process finish, in result window will show **Enroll OK (ID = 0) !** ID will automatically count for 1




6. Operation 4 – Verify

- If user ever enrolled and successful, you can use Icon [Verify 1:1] to demo
- The function will snap your finger to the current ID and show the result.



7. Operation 5 – Identify

- If user ever enrolled more than 1 IDs and successful, you can use Icon [Identify 1:N] to demo
- The function will snap your finger to the All IDs and show the result.



8. Operation 5 – Delete ID or Delete All

- If user ever delete ID, you can use Icon [Delete ID] or [Delete All] to demo
- While you select the function, AP will notice you and make sure if you want to do or not.

